

Starting the Engine	28
Steering Lock	27
Stopping Engine	101
Storage	
Equipment	31
Owner's Manual	32, 101
Storing Your Motorcycle	104
Switches	26
T	
Tachometer	18
Throttle	74
Tires	
Air Pressure	49
Puncture	85
Replacing	49
Transporting Your Motorcycle	105
Tripmeter	20, 101
Troubleshooting	80
Turn signal indicators	25
Turn Signal Switch	26

V

Vehicle Identification Number	107
-------------------------------------	-----

W

Warning Indicators ON	83
Warranty Coverage and Service	117
Washing Your Motorcycle	102
Weight Limit	15, 121

Wheels

Front removal	86
Rear removal	90