


Storage Equipment *(Continued)*

Tool kit

Center compartment

- ▶ Do not store any items that are flammable or susceptible to heat damage.

Rubber strap



Tool kit

A tool kit is located under the seat.

- ▶ The tool kit is held in the center compartment by a rubber strap.

Removing the Seat  **P.64**