

- **5.** Disconnect the negative \bigcirc terminal from the battery.
- **6.** Disconnect the positive \oplus terminal from the battery.
- **7.** Lift the battery strap with one hand while supporting the battery.
- **8.** Remove the battery taking care not to drop the terminal nuts.

I Installation

Install the parts in the reverse order of removal. Always connect the positive \oplus terminal first. Make sure that bolts and nuts are tight.

Make sure the clock information is correct after the battery is reconnected. ▶ P. 27 For proper handling of the battery, see "Maintenance Fundamentals." ▶ P. 50 "Battery Goes Dead." ▶ P. 106