

Equipment

Helmet Holder	38
Owner's Manual	39, 113
Tool kit	40

F

Flooded Engine	35
----------------------	----

Front Suspension	88
------------------------	----

Fuel

Consumption Meter	22
Gauge	21
Mileage Meter	22
Recommended	37
Remaining	21
Tank Capacity	37

Fuses	52, 109
-------------	---------

G

Gasohol	127
---------------	-----

Gasoline	37
----------------	----

Gear Position Indicator	21
-------------------------------	----

H

Hazard Switch	32
---------------------	----

Headlight Aim	86
---------------------	----

Headlight Dimmer Switch	32
-------------------------------	----

Helmet Holder	38
---------------------	----

High Beam Indicator	30
---------------------------	----

High Oil Temperature Indicator	29
--------------------------------------	----

Honda Contacts	131
----------------------	-----

Horn Button	32
-------------------	----

I

Ignition Cut-off System

Banking Sensor	114
----------------------	-----

Side Stand	77
------------------	----

Ignition Key	112
--------------------	-----

Ignition Switch	33, 35, 113
-----------------------	-------------

Indicators	29
------------------	----

Information Record	137
--------------------------	-----

Instruments	20
-------------------	----

L

Labels	7
--------------	---

Load Limits	14
-------------------	----

Loading Guidelines	14
--------------------------	----

Low Oil Pressure Indicator	29, 93
----------------------------------	--------