

Instruments & Controls

This section shows the location of all gauges, indicators, and controls you would normally use before or while riding your motorcycle.

The items listed on this page are described in this section. Instructions for other components are presented in other sections of this manual where they will be most useful.

Operation Component Locations	11
Gauges, Indicators & Displays.....	14
Multi-function Display.....	23
Fuel Gauge.....	24
Coolant Temperature Meter	26
Speedometer	28
Odometer/Tripmeter A & B.....	29
Selecting the Brightness of Display....	30
Digital Clock	31
Changing the Speed and Mileage Unit	34
Changing the Temperature Unit	35

(cont'd)