

Servicing Your Honda

Service Preparations

Maintenance Component Locations	89
Tool Kit.....	92
Owner's Manual Storage.....	93
Seat Removal.....	94
Left Side Cover Removal.....	96
Clip Removal.....	97

Service Procedures

Fluids & Filters

Fuel	98
Engine Oil & Filter.....	101
Coolant.....	111
Air Cleaner	115
Crankcase Breather	118

Engine

Throttle	120
Clutch System.....	122

Chassis

Suspension	125
Brakes	133
Tires	140
Side Stand.....	149
Drive Chain	150

Electrical

Battery	157
Appearance Care	162