

Inspecting the Brake Pads

Check the condition of the brake pad groove wear indicators.

Front (CB1000R ABS) The pads need to be replaced if a brake pad is worn to the groove.

Front (CB1000R) The pads need to be replaced if a brake pad is worn to the bottom of the groove.

Rear The pads need to be replaced if a brake pad is worn to the bottom of the groove.

