

Clip

Removal

1. Press down on the center pin to release the lock.
2. Pull the clip out of the hole.



Installation

1. Push the bottom of the center pin.
-
- The diagram consists of two parts. The left part shows a center pin being pushed into a hole, indicated by a downward-pointing arrow. The right part shows the clip being inserted into the hole, indicated by a rightward-pointing arrow.
2. Insert the clip into the hole.
 3. Press down on the center pin to lock the clip.