The average fuel mileage and fuel consumption will be based on tripmeter A.

- Current fuel mileage:
 Current instant fuel mileage. If your speed is less than 5 mph (7 km/h), " is displayed.
 When " is displayed at speeds above 5 mph (7 km/h), go to your dealer for service.
- Average fuel mileage:
 Average fuel mileage since tripmeter A was reset. When " " is displayed, go to your dealer for service.
- Fuel consumption:
 Total fuel consumption since tripmeter A was reset. When """ is displayed, go to your dealer for service.
 - □ To reset the average fuel mileage and fuel consumption: →P.22