

Storing Your Honda

Removal from Storage

Refer to *Safety Precautions* on page 92 .

1. Uncover and clean your motorcycle.
2. If your motorcycle has been stored for more than four months — change the engine oil (page 120).
3. If your motorcycle has been stored for more than two months — ask your Honda dealer to drain and replace the fuel.
4. Charge the battery (page 172) as required. Install the battery.
5. Lubricate the drive chain (page 166).
6. Perform a pre-ride inspection (page 59), then test-ride your motorcycle at low speeds.