

## Instruments *(Continued)*

### To Reset the Tripmeter and Tripmeter A Fuel Consumption

To reset tripmeter A and tripmeter A fuel consumption together, press and hold the **MODE** button with the tripmeter A or tripmeter A fuel consumption displayed.

#### Tripmeter A

TRIP A  
125.0 mile

or

#### Tripmeter A fuel consumption

TRIP A CONS.  
15.0 GAL



TRIP A  
0.0 mile

or

TRIP A CONS.  
-.- GAL

To reset the tripmeter B, press and hold the **MODE** button with the tripmeter B displayed.

TRIP B  
250.0 mile

**Tripmeter B**



TRIP B  
0.0 mile