


Instruments (Continued)



➡ Press the **MODE** button

➡ Press and hold the **MODE** button and **SEL ▲** (up) or **SEL ▼** (down) button

➡ Press the **SEL ▲** (up) button

➡ Press the **SEL ▼** (down) button

To end the setting

Select the "EXIT" menu on the main menu screen, or press and hold the **MODE** button and **SEL ▲** (up) or **SEL ▼** (down) button. Also, the setting mode is ended when your motorcycle speed reaches approximately 1 km/h (1 mph).

- ▶ Press and hold the **MODE** button and **SEL ▲** (up) or **SEL ▼** (down) button to return to the ordinary display.

Note that doing so cancels the settings left incomplete.