## **Instruments** (Continued)

## **Mechanic Mode**

Displays the current information of the motorcycle.

Displays the following information:

- Tachometer
- Gear position
- Throttle grip position
- Coolant temperature
- Battery voltage

## Throttle grip position

