## INFO<sub>2</sub>

You can select the "REV", "INST.CONS.", "AVG.CONS.", "TRIP A CONS.", "AVG.SPD." or "ELAPSED" for INFO 2.

- 1 Select the "INFO 2" using the SEL ▲ (up) or SEL ▼ (down) button, and press the MODE button.
  - Press and hold the SEL ▲ (up) or SEL (down) button to move the menu quickly.



- ② Select the "REV", "INST.CONS.",

  "AVG.CONS.", "TRIP A CONS.", "AVG.SPD."

  or "ELAPSED" using the SEL ▲ (up) or SEL

  √ (down) button.
  - Press and hold the SEL (up) or SEL (down) button to move the menu quickly.



3 Press the MODE button. The "INFO 2" setting is set, and then the display returns to the upper level hierarchy.