BACKGROUND

You can change the setting of the background to one of the four categories or select the auto adjustment.

- ① Select the "AUTO", "WHITE", "BLACK",
 "METALLIC" or "CARBON" using the SEL
 (up) or SEL
 (down) button.
 - Press and hold the SEL ▲ (up) or SEL ▼ (down) button to move the menu quickly.
- 2 Press the MODE button. The background setting is set, and then the display returns to the upper level hierarchy.

12:34	SETTING	0 km/h
FUNCTION	SHIFT INDICATOR	METALIC
LAP TIME	BRIGHTNESS	CARBON
DISPLAY	BACKGROUND	AUTO
GENERAL	USER LETTER	WHITE
SERVICE	FAVORITE	BLACK