

Stop Switch.....	24, 26, 95
Stopping.....	95
Environment.....	100

## F

Flooded Engine.....	26
Front Seat.....	50

## Fuel

Gauge.....	19
Recommended.....	28
Remaining.....	19
Tank Capacity.....	28

Fuses.....	41, 90
------------	--------

## G

Gasohol.....	108
Gasoline.....	28, 108

## H

Headlight Aim.....	74
Headlight Dimmer Switch.....	24
Helmet Holder.....	29
High Beam Indicator.....	23

Honda Contacts.....	111
Horn Button.....	24

## I

### Ignition Cut-off System

Banking Sensor.....	95
Side Stand.....	63

Ignition Key.....	94
-------------------	----

Ignition Switch.....	25, 26
----------------------	--------

Indicators.....	22
-----------------	----

Information Record.....	117
-------------------------	-----

Instruments.....	18
------------------	----

## L

Labels.....	7
-------------	---

Load Limits.....	15
------------------	----

Loading Guidelines.....	15
-------------------------	----

## M

### Maintenance

Fundamentals.....	36
-------------------	----

Importance.....	31
-----------------	----

Safety.....	32
-------------	----