

# Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

An optional larger tool kit may be available. Check with your Honda dealer’s parts department.

<b>Importance of Maintenance</b> .....	P. 31	<b>Air Cleaner</b> .....	P. 63
<b>Maintenance Schedule</b> .....	P. 33	<b>Coolant</b> .....	P. 64
<b>Maintenance Fundamentals</b> .....	P. 36	<b>Brakes</b> .....	P. 66
<b>Removing &amp; Installing Body Components</b> ...	P. 49	<b>Side Stand</b> .....	P. 68
Rear Seat.....	P. 49	<b>Drive Chain</b> .....	P. 69
Front Seat.....	P. 50	<b>Clutch</b> .....	P. 73
Middle Fairing .....	P. 51	<b>Throttle</b> .....	P. 76
Right Under Fairing.....	P. 53	<b>Crankcase Breather</b> .....	P. 77
Battery .....	P. 54	<b>Other Adjustments</b> .....	P. 78
Clip .....	P. 55	Rear Suspension.....	P. 78
Harness Band Clip .....	P. 55	Headlight Aim.....	P. 79
<b>Spark Plug</b> .....	P. 56	Brake Light Switch .....	P. 80
<b>Engine Oil</b> .....	P. 59		