The average fuel mileage and fuel consumption will be based on tripmeter A.

- Current fuel mileage: Current instant fuel mileage. If your speed is less than 5 mph (7 km/h), "---" is displayed. When "---" is displayed at speeds above 5 mph (7 km/h), go to your dealer for service.
- Average fuel mileage:
 Average fuel mileage since tripmeter A was reset. When "---" is displayed, go to your dealer for service.
- Fuel consumption:
 Total fuel consumption since tripmeter A was reset. When "----" displayed, go to your dealer for service
 - ► To reset the average fuel mileage and fuel consumption: ►P.22