The average fuel mileage and fuel consumption will be based on tripmeter A.

- Current fuel mileage:
   Current instant fuel mileage. If your speed is less than 5 mph (7 km/h), " is displayed.
- When " is displayed at speeds above 5 mph (7 km/h), go to your dealer for service.

   Average fuel mileage:
  - Average fuel mileage since tripmeter A was reset. When " is displayed, go to your dealer for service.
- Fuel consumption:
  Total fuel consumption since tripmeter A was reset. When "" is displayed, go to your dealer for service.
  - ► To reset the average fuel mileage and fuel consumption: →P.22