Tire Puncture ► Removing Wheels

CBR500RA only

When removing and installing the wheel, be careful not to damage the wheel speed sensor and pulser ring.

I Front Wheel

Removal

- **1.** Place your motorcycle on a firm, level surface.
- **2.** Cover the right side of the front wheel and brake caliper with protective tape or cloth.
- **3.** On the right side, remove the mounting bolts and brake caliper.
 - Support the brake caliper assembly so that it doesn't hang from the brake hose. Do not twist the brake hose.
 - Avoid getting grease, oil, or dirt on the disc or pad surfaces.
 - ▶ Do not pull the front brake lever while the brake caliper is removed.

➤ Take care to prevent the brake caliper from scratching the wheel during removal.

