


← Left turn signal indicator



⇒ Right turn signal indicator

☰ High beam indicator

N Neutral indicator

Comes on when the transmission is in Neutral.