

Instruments *(Continued)*

Current fuel mileage

Displays the current instant fuel mileage.
Display range: 0.0 to 299.9 mile/gal (L/100km or km/L)

- Initial display: "---.-" is displayed.
- When your speed is less than 4 mph (6 km/h): "---.-" is displayed.
- More than 299.9 mile/gal (L/100km or km/L) : "299.9" is displayed.

When "---.-" is displayed except for the above-mentioned cases, go to your dealer for service.

Reserve fuel consumption [RES]

Displays the fuel consumption since the 1st (E) segment of the fuel gauge starts flashing. When the 1st (E) segment of the fuel gauge starts flashing, the odometer, tripmeter A, tripmeter B, average fuel mileage A, average fuel mileage B or current fuel mileage switches to the reserve fuel consumption. You should refill the tank as soon as possible.
Display range: 0.0 to 99.9 gal (gallon) or 0.0 to 99.9 L (liters)

- Flashes from "0.0"
- More than 99.9 gal (gallon) or 99.9 L (liters) : "99.9" is displayed.

After refueling more than the reserve amount, the display returns to normal.

When "---.-" is displayed, go to your dealer for service.