


Clip

Removal

1. Press down on the center pin to release the lock.
2. Pull the clip out of the hole.



Installation


1. Push the bottom of the center pin.
2. Insert the clip into the hole.
3. Press down on the center pin to lock the clip.



Harness Band Clip

Removal

Pull the harness band clip while pressing both sides of the anchor.



Installation

Install the harness band clip until it seats properly.