

Instruments *(Continued)*

Current fuel mileage

Displays the current or instant fuel mileage.

AC, II AC, IV AC type

Display range: 0.0 to 300.0 mpg (mile/L, km/L or L/100km)

- When your speed is less than 6 km/h (4 mph): "---.-" is displayed.
- More than 300.0 mpg (mile/L or L/100km): "---.-" is displayed.
More than 300.0 km/L: "300.0" is displayed.

CM, IV CM type

Display range: 0.0 to 300.0 L/100km (km/L, mpg or mile/L)

- When your speed is less than 6 km/h (4 mph): "---.-" is displayed.
- More than 300.0 L/100km (mpg or mile/L): "---.-" is displayed.
More than 300.0 km/L: "300.0" is displayed.

When "---.-" is displayed except for the above-mentioned cases, go to your dealer for service.