

G switch

CRF1000D

The G switch can change the engine characteristics of your motorcycle to help improve traction and machine control for off-road riding by reducing the amount of clutch slip during throttle operation.

- u Each time the ignition switch is turned to the ON position, the G switch will automatically be set to off.
- u The G switch may not compensate for rough road conditions.

Always consider road and weather conditions, as well as your skills and condition, when applying throttle.

G switch on or off

- 1 Stop the motorcycle and close the throttle completely.
- 2 Press the G switch.

