To Reset the Tripmeter B [TRIP B], **Tripmeter B Average Fuel Mileage** [AVG. CONS.], Tripmeter B Average Speed [AVG. SPD.], Tripmeter B Fuel Consumption [CONS.] and Tripmeter B **Elapsed [ELAPSED]**

To reset the tripmeter B [TRIP B], tripmeter B average fuel mileage [AVG. CONS.], tripmeter B average speed [AVG. SPD.], tripmeter B fuel consumption [CONS.] and tripmeter B elapsed [ELAPSED], press and hold the **ENT** switch while page 2 is displayed or touch and hold the page 2 area.

1	2	3	4
TRIP B	1910		
	1.	50.0	mi
AVG. C	ONS.		
		50.0	mpg
AVG. S	PD.		
		30	mph
CONS.			
		1.2	gal