[P] Power value (Engine output level)

[P] Power value has four setting levels.

Available setting range: 1 to 4

- u Level 1 has the maximum power.
- u Level 4 has the minimum power.

[EB] Engine brake value (Engine brake level)

EB value has three setting levels.

Available setting range: 1 to 3

- u Level 1 has the strongest engine braking effect.
- u Level 3 has the weakest engine braking effect.

[S] Overall: suspension damping

CRF1100A4/D4

[S] Overall value has four setting levels. Available setting range: [H] Hard / [M] Medium / [S] Soft / [O] Off Road

- u [H] Hard has the maximum suspension damping.
- u [S] Soft has the minimum suspension damping.
- u [O] Off Road is for off road settings.

[Front]: suspension damping

CRF1100A4/D4

[Front] has three setting levels.

Available setting range: - / Medium / +

- u + has the maximum suspension damping.
- u has the minimum suspension damping.