| Symptom                                    | Cause/remedy   |
|--|--|
| Bluetooth® handsfree                       | Connected <i>Bluetooth</i> ® device may be an unsupported device.<br>Check the supported <i>Bluetooth</i> ® version/profiles. <b>2</b> P. 153                    |
|  | When the <i>Bluetooth</i> ® connection is unstable due to surrounding conditions or radio wave conditions, the handsfree calling functions may not be available. |
|  | To use <i>Bluetooth®</i> handsfree calling, a headset connection is necessary. Connect a paired headset. <b>2</b> P. 159   |
| During a call, headset volume is low/high. | Adjust the volume during a call. 2 P. 92   |
| Passenger's headset is no sound            | Passenger headset only outputs music. Music playback is interrupted while using the handsfree phone or Siri.   |