


Audio System (Continued)

To disconnect functions:

- 2 [Phone Pairing]
1. Select [Phone Pairing], and then press the **ENT** switch to enter the setting menu.



2. Select the paired device, and then press the **ENT** switch.

