

## Audio System (Continued)

### Preparation

- 1 Connect with the paired mobile phone. **▶ P.154**
  - ▶ The phonebook is updated after every connection. Call history is updated after every connection or call.
- 2 Connect the paired rider headset. **▶ P.159**
- 3 Select [Phone], and then press the **ENT** switch.



- 4 Return to the riding information, previous screen or Home screen. **▶ P.38**  
You can also perform the above settings by using the touch screen.

### Making a Call

You can make calls by inputting a phone number or by using the phonebook, call history or speed dial entries.

To change the call mode, push **◀** or **▶** on the **◀▶** sel left/right switch.

Changes the call modes as follows:

[Call History] **↔** [Speed Dial] **↔** [Contacts] **↔** [Dial Number] **↔** [Settings]

- Certain manual functions are disabled while the vehicle is in motion. You cannot select a greyed-out option until the vehicle is stopped.

- Only previously stored speed dial entries and call history can be called while the vehicle is in motion.

**To adjust the phone volume:** **▶ P.91**