


Storage Equipment (Continued)

Fuse Puller, Hex Wrench, Standard/Phillips Screwdriver, Screwdriver Handle

The fuse puller, hex wrench, standard/phillips screwdriver and screwdriver handle are located on the underside of the rear seat.

**Standard/Phillips
screwdriver**

Hex wrench



Screwdriver handle


Fuse puller

Tool Kit

Canada

The tool kit is located in the tool box.

Tool box



Tool kit

Removing the rear seat **P.253**

Removing the tool box **P.257**