

Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

Importance of Maintenance	P. 225	Spark Arrester	P. 258
Maintenance Schedule	P. 227	Engine Oil	P. 260
Maintenance Record	P. 230	Coolant	P. 262
Maintenance Fundamentals	P. 231	Brakes	P. 264
Tool	P. 247	Side Stand	P. 268
Removing & Installing Body Components	P. 248	Drive Chain	P. 269
Battery	P. 248	Wheels	P. 271
Battery Box Cover	P. 249	Clutch	P. 273
Clip.....	P. 250	Throttle	P. 276
Front Seat.....	P. 251	Other Adjustments	P. 277
Rear Seat.....	P. 253	Adjusting the Brake Lever	P. 277
Skid Plate	P. 255	Adjusting the Front Suspension	P. 278
Tool Box	P. 257	Adjusting the Rear Suspension	P. 282
		Adjusting the Windscreen Height	P. 288