

Index

A

accessories	3
adjustments,	
altitude and temperature	117
carburetor	110
chassis	123
control freerplay	46, 49, 51
engine idle speed	48
for competition	93
gearing	124
personal fit	126
suspension, front	94
suspension, rear	102
suspension, track conditions	106
tire selection	125
after competition maintenance	26
air cleaner	43
air pressure,	
front suspension	94
tires	80
appearance care	90
authorized manuals	148

B

basic operation	11
before riding	7
between motos & practice maintenance	26
brakes,	
fluid level	76
lever, front adjustment	75
pad wear	78
pedal height	75
break-in guidelines	16

C

capacity, fuel	34
carburetor,	
adjustment	110
circuit functions	112
components	110
disassembly/assembly	114
idle speed	48
minor adjustments	120
optional muffler settings	118
care, appearance	90
chain drive	82
chassis adjustments	123
choke knob	13
cleaner, air	43
cleaning, appearance care	90
clutch system, adjustment	49
competition logbook	141
consumer information	147
contacting Honda	149
controls, operating	5
coolant	41
customer service	149
cylinder system	62

D

damping adjustments,	
front	100
rear	103
dealer, your Honda	150
diagram, wiring	146
drive chain	82

E

engine,	
flooded	13
idle speed	48
number	134
oil	36
pinging	34
starting	13
stop button	14
stopping	14
won't start	13
environment, protecting	130

F

filter,	
air	43
oil	37
flooded engine, starting	13
fork,	
front suspension adjustment	94
front suspension inspection	70
oil recommendation	72
front brake lever adjustment	75
front suspension maintenance	70
fuel,	
line	34
filter	35
recommendation	34
refueling	34
system	34
oxygenated	140
tank capacity	34
valve	13