Operating Controls

Read this section carefully before you ride. It presents the location of the basic controls on your CRF.	Operation Component Locations6	