

Contents

MOTORCYCLE SAFETY	1	<i>Service Procedures</i>		TIPS	127
Important Safety Information	2	Fluids & Filters		Transporting Your Motorcycle	128
Important Safety Precautions	2	Fuel System	34	Storing Your Honda	129
Important Message to Parents	2	Engine Oil	36	You & the Environment	130
Accessories & Modifications	3	Transmission Oil	39	Troubleshooting	131
Safety Labels	4	Coolant	41	TECHNICAL INFORMATION	133
OPERATING CONTROLS	5	Air Cleaner	43	Vehicle Identification	134
Operation Component Locations	6	Crankcase Breather	45	Specifications	135
BEFORE RIDING	7	Engine		Torque Specifications	137
Are You Ready to Ride?	8	Throttle	46	Oxygenated Fuels	140
Is Your Motorcycle Ready to Ride?	9	Engine Idle Speed	48	Competition Logbook	141
Pre-ride Inspection	9	Clutch System	49	Optional Parts List	143
BASIC OPERATING INSTRUCTIONS	11	Hot Start Lever	51	Spare Parts & Equipment	145
Safe Riding Precautions	12	Spark Plug	52	Wiring Diagram	146
Starting & Stopping the Engine	13	Valve Clearance	53	CONSUMER INFORMATION	147
Preparation	13	Piston/Piston Rings/Piston Pin	62	Authorized Manuals	148
Starting Procedure	13	Chassis		Contacting Honda	149
Flooded Engine	13	Suspension	70	Your Honda Dealer	150
How to Stop the Engine	14	Brakes	75	The Honda Rider's Club (USA only)	151
Shifting Gears	15	Wheels	79	INDEX	152
Break-in Guidelines	16	Tires & Tubes	80	QUICK REFERENCE	
SERVICING YOUR HONDA	17	Drive Chain	82		
<i>Before You Service Your Honda</i>		Exhaust Pipe/Muffler	85		
The Importance of Maintenance	18	Additional Maintenance Procedures	88		
Maintenance Safety	19	Appearance Care	90		
Important Safety Precautions	19	ADJUSTMENTS FOR COMPETITION	93		
Maintenance Schedule	20	Front Suspension Adjustments	94		
General Competition Maintenance	22	Rear Suspension Adjustments.....	102		
Before & After Competition Maintenance	26	Suspension Adjustments for Track			
Between Motos & Practice Maintenance	26	Conditions	106		
After Competition Maintenance.....	26	Suspension Adjustment Guidelines	107		
<i>Service Preparations</i>		Carburetor Adjustments & Tuning Tips	110		
Maintenance Component Locations	28	Chassis Adjustments	123		
Seat	29	Gearing	124		
Fuel Tank	30	Tire Selection for Track Conditions	125		
Subframe	32	Personal Fit Adjustments	126		