

Keeping your CRF well maintained is absolutely essential to your safety. It’s also a good way to protect your investment, get maximum performance, avoid breakdowns, and have more fun.

To help keep your CRF in good shape, this section includes a Maintenance Schedule for required servicing and step-by-step instructions for specific maintenance tasks. You’ll also find important safety precautions, information on oils, and tips for keeping your Honda looking good.

An ICM (Ignition Control Module) system is used on this motorcycle; consequently, routine ignition timing adjustment is unnecessary. If you want to check the ignition timing, refer to the Honda Service Manual (page 148).

An optional tool kit may be available. Check with your dealer’s parts department.

Before You Service Your Honda

The Importance of Maintenance 18

Maintenance Safety 19

 Important Safety Precautions 19

Maintenance Schedule 20

General Competition Maintenance 22

Before & After Competition Maintenance 26

 Between Motos & Practice Maintenance 26

 After Competition Maintenance 26

Service Preparations

Maintenance Component Locations 28

Seat 29

Fuel Tank 30

Subframe 32

Service Procedures

Fluids & Filters

Fuel System 34

Engine Oil 36

Transmission Oil 39

Coolant 41

Air Cleaner 43

Crankcase Breather 45

Engine

Throttle 46

Engine Idle Speed 48

Clutch System 49

Hot Start Lever 51

Spark Plug 52

Valve Clearance 53

Piston/Piston Rings/Piston Pin 62

Chassis

Suspension 70

 Front Suspension Inspection 70

 Rear Suspension Inspection 71

 Recommended Fork Oil 72

 Fork Oil Change 72

Brakes 75

Wheels 79

Tires & Tubes 80

Drive Chain 82

Exhaust Pipe/Muffler 85

Additional Maintenance Procedures 88

Appearance Care 90