

# Index

## R

- rear suspension maintenance ..... 71
- Rider's Club Honda..... 151
- riding,
  - basic operation..... 11
  - before..... 7
  - important safety information..... 2
  - safety precautions..... 19

## S

- safety,
  - a few words about .....Safety Messages
  - important information ..... 2
  - important precautions..... 2
  - labels..... 4
  - maintenance..... 19
  - riding precautions..... 2
- schedule, maintenance..... 20
- seat..... 29
- serial numbers..... 134
- service,
  - customer ..... 148
  - manuals..... 151
- spare parts..... 145
- spark knock..... 34
- spark plug,
  - maintenance..... 52
  - reading ..... 122
- specifications ..... 135,136
- spring pre-load, rear suspension..... 102
- starting,
  - engine ..... 13
  - troubleshooting..... 131
- steering stem inspection ..... 88
- stopping engine..... 14
- storage ..... 129
- subframe ..... 32

- suspension,
  - front..... 70,94
  - rear ..... 71,102
- suspension adjustment,
  - front..... 94
  - rear ..... 102
  - for track conditions ..... 106
  - guidelines ..... 107

## T

- transmission oil ..... 39
- tuning tips..... 110
- throttle,
  - freeplay ..... 46
  - inspection ..... 47
- tires,
  - air pressure..... 80
  - flat ..... 80
  - selection ..... 81
- tools..... 145
- torque specifications
  - carburetor ..... 116
  - engine..... 137
  - frame ..... 138-139
- transporting ..... 128
- troubleshooting ..... 131
- tubes, replacing ..... 80

## V

- valve, fuel..... 13
- valve clearance..... 54
- vehicle identification no. (VIN)..... 134

## W

- washing your motorcycle ..... 90
- wheels ..... 79
- wiring diagram..... 146