

ADJUSTMENTS FOR COMPETITION... 133
Engine Mode Select Button 134
 Current Mode 134
 Mode Selection..... 134
Front Suspension Adjustments 135
 Right Front Suspension Air Pressure 135
 Front Suspension Damping (Right Fork) 136
 Fork Springs (Left Fork) 136
Rear Suspension Adjustments 140
 Rear Suspension Spring Pre-Load..... 140
 Rear Suspension Damping 141
 Rear Suspension Race Sag 142
Suspension Adjustments for Track
 Conditions 144
 Suspension Adjustment Guidelines 145
 Tuning Tips 148
 Spark Plug Reading 148
Steering Damper Adjustment 149
 Steering Damper Damping 149
Steering Damper Adjustment Guidelines 150
Chassis Adjustments 151
 Rear End 151
 Fork Height/Angle..... 151
 Wheelbase 151
Gearing 152
Tire Selection for Track Conditions 153
Personal Fit Adjustments 154
 Control Positioning 154
 Handlebar Position, Width & Shape 154

TIPS..... 155
Transporting Your Motorcycle 156
Storing Your Honda 157
 Preparation for Storage 157
 Removal from Storage 157
You & the Environment 158
Troubleshooting 159

TECHNICAL INFORMATION..... 161
Vehicle Identification 162
 Serial Numbers 162
Specifications 163
Torque Specifications 164
 Nuts, Bolts, Fasteners 164
Oxygenated Fuels 167
Competition Logbook 168
Optional Parts List 170
Spare Parts & Equipment 171
 Spare Parts 171
 General Tools..... 171
 Honda Special Tools..... 171
 Chemical Products 171
 Other Products 171
Wiring Diagram 172

CONSUMER INFORMATION 173
Authorized Manuals 174
Contacting Honda 175
Your Honda Dealer 176
The Honda Rider’s Club (USA only) 177

INDEX 178
QUICK REFERENCE