

# Contents

---

<b>MOTORCYCLE SAFETY.....</b>	<b>1</b>
Important Safety Information .....	2
Important Safety Precautions .....	2
Accessories & Modifications .....	3
Safety Labels .....	4
 <b>INSTRUMENTS &amp; CONTROLS.....</b>	 <b>5</b>
Operation Component Locations .....	6
MIL (Malfunction Indicator Lamp) .....	7
MIL Blink Pattern .....	7
Current DTC/Freeze DTC .....	7
Circuit Inspection .....	8
DTC Index.....	9
Mode Indicator .....	10
 <b>BEFORE RIDING.....</b>	 <b>11</b>
Are You Ready to Ride? .....	12
Is Your Motorcycle Ready to Ride? .....	13
Pre-ride Inspection .....	13
 <b>BASIC OPERATING INSTRUCTIONS ....</b>	 <b>15</b>
Safe Riding Precautions .....	16
Starting & Stopping the Engine .....	17
Fast Idle Knob .....	17
Preparation .....	17
Starting Procedure .....	17
How to Stop the Engine .....	18
Break-in Guidelines .....	19

<b>SERVICING YOUR HONDA .....</b>	<b>21</b>
<i>Before You Service Your Honda</i>	
The Importance of Maintenance .....	22
Maintenance Safety .....	23
Important Safety Precautions.....	23
Maintenance Schedule .....	24
General Competition Maintenance .....	26
Before & After Competition Maintenance .....	30
Between Motos & Practice Maintenance.....	30
After Competition Maintenance .....	32
<i>Service Preparations</i>	
Maintenance Component Locations .....	33
Seat .....	34
Fuel Tank .....	35
Subframe .....	38
<i>Service Procedures</i>	
<u>Fluids &amp; Filters</u>	
Fuel System .....	40
Engine Oil .....	49
Transmission Oil .....	52
Coolant .....	54
Air Cleaner .....	56
Crankcase Breather .....	58
<u>Engine</u>	
Throttle .....	59
Engine Idle Speed .....	61
Clutch System .....	62
Spark Plug .....	67
Valve Clearance .....	68
Piston/Piston Rings/Piston Pin .....	77

<u>Chassis</u>	
Suspension .....	87
Brakes .....	111
Wheels .....	115
Tires & Tubes .....	116
Drive Chain .....	118
Exhaust Pipe/Muffler .....	121
Steering Damper .....	125
Additional Maintenance Procedures .....	128
Appearance Care .....	130