

ADJUSTMENTS FOR COMPETITION ...	133	TIPS.....	155	INDEX	178
Engine Mode Select Button	134	Transporting Your Motorcycle	156	QUICK REFERENCE	
Current Mode	134	Storing Your Honda	157		
Mode Selection.....	134	Preparation for Storage	157		
Front Suspension Adjustments	135	Removal from Storage	157		
Right Front Suspension Air Pressure	135	You & the Environment	158		
Front Suspension Damping (Right Fork)....	136	Troubleshooting	159		
Fork Springs (Left Fork)	136				
Rear Suspension Adjustments	140	TECHNICAL INFORMATION.....	161		
Rear Suspension Spring Pre-Load.....	140	Vehicle Identification	162		
Rear Suspension Damping	141	Serial Numbers	162		
Rear Suspension Race Sag	142	Specifications	163		
Suspension Adjustments for Track		Torque Specifications	164		
Conditions	144	Nuts, Bolts, Fasteners	164		
Suspension Adjustment Guidelines	145	Oxygenated Fuels	167		
Tuning Tips	148	Competition Logbook	168		
Spark Plug Reading.....	148	Optional Parts List	170		
Steering Damper Adjustment	149	Spare Parts & Equipment	171		
Steering Damper Damping.....	149	Spare Parts	171		
Steering Damper Adjustment Guidelines	150	General Tools.....	171		
Chassis Adjustments	151	Honda Special Tools.....	171		
Rear End.....	151	Chemical Products	171		
Fork Height/Angle.....	151	Other Products	171		
Wheelbase	151	Wiring Diagram	172		
Gearing	152				
Tire Selection for Track Conditions	153	CONSUMER INFORMATION	173		
Personal Fit Adjustments	154	Authorized Manuals	174		
Control Positioning	154	Contacting Honda	175		
Handlebar Position, Width & Shape	154	Your Honda Dealer	176		
		The Honda Rider's Club (USA only)	177		