

# Index

## A

- accessories ..... 3
- adjustments,
  - chassis..... 151
  - control freeplay ..... 59, 62
  - for competition ..... 133
  - gearing..... 152
  - personal fit..... 154
  - steering damper ..... 149
  - suspension, front..... 135
  - tire selection, track condition ..... 153
- after competition maintenance ..... 32
- air cleaner ..... 56
- air pressure,
  - balance chamber ..... 139
  - inner chamber..... 137
  - outer chamber..... 138
  - right front suspension ..... 135
  - tires ..... 116
- apparel, protective ..... 2
- appearance care ..... 130
- authorized manuals..... 174

## B

- balance chamber air pressure ..... 139
- basic operation..... 15
- before riding ..... 11
- between motos & practice maintenance ..... 30
- brakes,
  - fluid level..... 112
  - lever, front adjustment..... 111
  - pad wear ..... 114
  - pedal height ..... 111
- break-in guidelines ..... 19

## C

- capacity, fuel..... 40
- care, appearance ..... 130
- chain drive..... 118
- chassis adjustments ..... 151
- cleaner, air..... 56
- cleaning, appearance care ..... 130
- clutch system, adjustment ..... 62
- competition logbook ..... 168
- consumer information ..... 173
- contacting Honda ..... 175
- controls..... 5
- coolant..... 54
- customer service..... 173
- cylinder system ..... 79

## D

- damping adjustments,
  - front..... 135, 136
  - rear ..... 141
  - steering damper..... 149
- dealer, your Honda..... 176
- diagram, wiring..... 172
- drive chain..... 118

## E

- engine,
  - flooded..... 17
  - idle speed..... 61
  - lacks power..... 159
  - mode select button..... 134
  - number..... 162
  - oil..... 49
  - starting ..... 17
  - stop button ..... 18
  - stopping ..... 18
  - won't start..... 159
- environment, protecting..... 17, 158

## F

- filter,
  - air..... 56
  - fuel pump..... 44
  - oil..... 50
- flooded engine, starting ..... 17
- fork,
  - front suspension inspection ..... 87
  - oil recommendation..... 91
- front brake lever adjustment..... 111
- front suspension maintenance..... 135
- fuel ..... 40
- fuel,
  - line inspection..... 40
  - line replacement ..... 41
  - oxygenated..... 167
  - pump filter ..... 44
  - refueling..... 40
  - system..... 40
  - tank capacity..... 40