

Engine

Idle Speed	39
Number	115
Oil.....	48, 63
Oil Filter	65
Overheats.....	88
Starting	30
Stop Switch.....	27, 108
Stopping	108
Will Not Start.....	87

F

Flooded Engine	30
----------------------	----

Fuel

Gauge	21
Recommended	32
Tank Capacity	32

Fuses.....	47, 101
------------	---------

G

Gasohol.....	121
Gasoline	32

H

Hazard Switch.....	26
Headlight Aim	85
Headlight Dimmer Switch	26
Helmet Holder	33
High Beam Indicator.....	25
High Coolant Temperature Indicator ...	25, 88
Honda Contacts	125
Horn Button	26

I

Ignition Cut-off System

Banking Sensor.....	108
---------------------	-----

Ignition Key.....	107
-------------------	-----

Ignition Switch.....	27, 108
----------------------	---------

Indicators	24
------------------	----

Information Record.....	131
-------------------------	-----

Instruments, Controls, & Other

Features	108
----------------	-----

K

Keys.....	107
-----------	-----