

Keeping your motorcycle well maintained is absolutely essential to your safety. It's also a good way to protect your investment, get maximum performance, avoid breakdowns, and have more fun.

To help keep your motorcycle in good shape, this section includes a Maintenance Schedule for required service, a list of periodic checks you should perform at least once a month, and step-by-step instructions for specific maintenance tasks. You'll also find important safety precautions, information on oils, and tips for keeping your motorcycle looking good.

For information about the exhaust emission and noise emission requirements of the U.S. Environmental Protection Agency (EPA), the California Air Resources Board (CARB), and the Environment and Climate Change Canada (ECCC) see page 184.

For information about replacing fuses, see page 172.

USA only  
**Maintenance, replacement or repair of the emission control devices and systems may be performed by any motorcycle repair establishment or individual using parts that are "certified" to EPA standards.**

An ECM system is used on this motorcycle; consequently, routine ignition timing adjustment is unnecessary. If you want to check the ignition timing, refer to an official Honda Service Manual (page 194).

An optional tool kit may be available. Check with your dealer's parts department.

*Before You Service Your Honda*

The Importance of Maintenance ..... 32

Maintenance Safety ..... 33

    Important Safety Precautions ..... 33

Periodic Maintenance ..... 34

Maintenance Schedule ..... 35

Maintenance Record (On-Road Use Only) ..... 38

General Competition Maintenance (Off-Road Use Only) ..... 39

Before & After Competition Maintenance (Off-Road Use Only) ..... 43

    Between Races & Practice Maintenance ..... 43

    After Competition Maintenance ..... 44

*Service Preparations*

Maintenance Component Locations ..... 45

Seat ..... 46

Side Cover ..... 47

Fuel Tank ..... 48

Subframe ..... 52

*Service Procedures*

Fluids & Filters

Fuel System ..... 60

Engine Oil ..... 69

Coolant ..... 72

Air Cleaner ..... 75

Crankcase Breather ..... 77

Engine

Throttle ..... 78

Engine Idle Speed ..... 80

Clutch System ..... 81

Spark Plug ..... 86

Valve Clearance ..... 87

Piston/Piston Rings/Piston Pin ..... 96

Chassis

Suspension ..... 105

    Front Suspension Inspection ..... 105

    Rear Suspension Inspection ..... 121

Brakes ..... 122

Wheels ..... 126

Tires & Tubes ..... 127

Side Stand ..... 129

Drive Chain ..... 130

Exhaust Pipe/Muffler ..... 133

Spark Arrester ..... 135

Additional Maintenance Procedures ..... 136

Electrical

Battery ..... 138

Headlight Aim ..... 140

Appearance Care ..... 141