

Index

A

- accessories 3
- adjustments 143
- adjustments,
 - chassis 154
 - control freeplay 78, 81, 122
 - personal fit 156
 - suspension, front 144
 - suspension, rear 146
 - tire selection, track condition 155
- after competition maintenance 44
- air cleaner 75
- air pressure,
 - front suspension 144
 - tires 127
- always carry this manual and tool kit 18
- appearance care 141
- authorized manuals 194

B

- backlight brightness adjustment 13
- bank angle sensor ignition cut-off system 26
- basic operation 23
- battery 138
- before riding 17
- between races & practice maintenance 43
- brakes,
 - fluid level 123
 - lever, front adjustment 122
 - pad wear 125
 - pedal height 122
- braking 28
- break-in guidelines 30
- burned-out light bulb 171

C

- capacity, fuel 60
- care, appearance 141
- catalytic converter 186
- chain drive 130
- changing the fuel mileage unit 14
- changing the speed and mileage unit 14
- chassis adjustments 154
- cleaner, air 75
- cleaning, appearance care 141
- consumer information 193
- contacting Honda 197
- controls 7
- coolant 72
- customer service 198
- cylinder system 98

D

- damping adjustments,
 - front 145
 - rear 147
- dealer, your Honda 198
- diagram, wiring 192
- digital clock setting 13
- drive chain 130

E

- emission control systems 184
- engine stop switch 15
- engine,
 - does not start 161
 - flooded 26
 - idle speed 80
 - lacks power 161
 - number 178
 - oil 69
 - pinging 60
 - starting 25
- environment, protecting 160

F

- filter,
 - air 75
 - fuel pump 63
 - oil 70
- flooded engine, starting 26
- fork,
 - front suspension adjustment 144
 - front suspension inspection 105
 - oil recommendation 108
- front brake lever adjustment 122
- front suspension maintenance 144
- fuel 60
- fuel mileage meter 12
- fuel system 60
- fuel tank 48
- fuel,
 - line inspection 61
 - line replacement 61
 - oxygenated 187
 - pump filter 63
 - refueling 60
 - tank capacity 60