

ADJUSTMENTS FOR COMPETITION..... 139
Front Suspension Adjustments 140
 Front Suspension Air Pressure 140
 Front Suspension Damping 141
 Fork Springs 141
 Fork Oil Adjustment..... 142
Rear Suspension Adjustments 143
 Rear Suspension Spring Pre-Load..... 143
 Rear Suspension Damping 144
 Rear Suspension Race Sag 146
Suspension Adjustments for Track Conditions 148
Suspension Adjustment Guidelines 149
Tuning Tips 152
 Spark Plug Reading..... 152
Chassis Adjustments 153
 Rear End..... 153
 Fork Height/Angle..... 153
 Wheelbase 153
Tire Selection for Track Conditions 154
Personal Fit Adjustments 155
 Control Positioning 155
 Handlebar Position, Width & Shape 155

TIPS..... 157
Transporting Your Motorcycle 158
Storing Your Honda 159
 Preparation for Storage 159
 Removal from Storage 159
You & the Environment 160
Troubleshooting 161

TAKING CARE OF THE UNEXPECTED..... 163
If a Fuse Blows 164
If Your Battery Is Low (or Dead) 165
If You Crash 166

TECHNICAL INFORMATION..... 167
Vehicle Identification 168
 Serial Numbers 168
Specifications 169
Torque Specifications 170
 Nuts, Bolts, Fasteners 170
Emission Control Systems 173
Oxygenated Fuels 175
Competition Logbook 176
Optional Parts List 178
Spare Parts & Equipment 179
 Spare Parts 179
 General Tools..... 179
 Honda Special Tools..... 179
 Chemical Products 179
 Other Products 179
Wiring Diagram 180

CONSUMER INFORMATION 181
Authorized Manuals 182
Warranty Coverage 183
Warranty Service 184
Contacting Honda 185
Your Honda Dealer 186

INDEX 188
QUICK REFERENCE