

Read this section carefully before you ride. It presents the location of the basic controls on your CRF.

Operation Component Locations	8
Indicators & Displays	9
Multi-function Display	10
Speedometer.....	12
Odometer/Tripmeter A & B.....	12
Fuel Mileage Meter.....	12
Digital Clock Setting	13
Backlight Brightness Adjustment	13
Changing the Speed and Mileage Unit	14
Changing the Fuel Mileage Unit.....	14