

<b>ADJUSTMENTS FOR COMPETITION.....</b>	<b>139</b>	<b>TIPS.....</b>	<b>157</b>	<b>INDEX .....</b>	<b>188</b>
Front Suspension Adjustments .....	140	Transporting Your Motorcycle .....	158	<i><b>QUICK REFERENCE</b></i>	
Front Suspension Air Pressure .....	140	Storing Your Honda .....	159		
Front Suspension Damping .....	141	Preparation for Storage .....	159		
Fork Springs .....	141	Removal from Storage .....	159		
Fork Oil Adjustment.....	142	You & the Environment .....	160		
Rear Suspension Adjustments .....	143	Troubleshooting .....	161		
Rear Suspension Spring Pre-Load.....	143				
Rear Suspension Damping .....	144	<b>TAKING CARE OF</b>			
Rear Suspension Race Sag .....	146	<b>THE UNEXPECTED.....</b>	<b>163</b>		
Suspension Adjustments for Track		If a Fuse Blows .....	164		
Conditions .....	148	If Your Battery Is Low (or Dead) .....	165		
Suspension Adjustment Guidelines .....	149	If You Crash .....	166		
Tuning Tips .....	152				
Spark Plug Reading.....	152	<b>TECHNICAL INFORMATION.....</b>	<b>167</b>		
Chassis Adjustments .....	153	Vehicle Identification .....	168		
Rear End.....	153	Serial Numbers .....	168		
Fork Height/Angle.....	153	Specifications .....	169		
Wheelbase .....	153	Torque Specifications .....	170		
Tire Selection for Track Conditions .....	154	Nuts, Bolts, Fasteners .....	170		
Personal Fit Adjustments .....	155	Emission Control Systems .....	173		
Control Positioning .....	155	Oxygenated Fuels .....	175		
Handlebar Position, Width & Shape .....	155	Competition Logbook .....	176		
		Optional Parts List .....	178		
		Spare Parts & Equipment .....	179		
		Spare Parts .....	179		
		General Tools.....	179		
		Honda Special Tools.....	179		
		Chemical Products .....	179		
		Other Products .....	179		
		Wiring Diagram .....	180		
		<b>CONSUMER INFORMATION .....</b>	<b>181</b>		
		Authorized Manuals .....	182		
		Warranty Coverage .....	183		
		Warranty Service .....	184		
		Contacting Honda .....	185		
		Your Honda Dealer .....	186		