

Index

A

- accessories 4
- adjustments,
 - chassis 153
 - control freeplay 72, 75, 116
 - for competition 139
 - personal fit 155
 - suspension, front 140
 - suspension, rear 143
 - suspension, track conditions 148
 - tire selection, track condition 154
- after competition maintenance 41
- air cleaner 69
- air pressure,
 - front suspension 140
 - tires 121
- apparel, protective 2
- appearance care 136
- authorized manuals 182

B

- backlight brightness adjustment 13
- basic operation 19
- battery 133
- before riding 15
- between motos & practice maintenance 40
- brakes,
 - fluid level 117
 - lever, front adjustment 116
 - pad wear 119
 - pedal height 116
- break-in guidelines 23, 27

C

- capacity, fuel 54
- care, appearance 136
- chain drive 124
- changing the fuel mileage unit 14
- changing the speed and mileage unit 14
- chassis adjustments 153
- cleaner, air 69
- cleaning, appearance care 136
- competition logbook 176
- consumer information 181
- controls 7
- coolant 66
- customer service 186
- cylinder system 92

D

- damping adjustments,
 - front 141
 - rear 144
- dealer, your Honda 186
- diagram, wiring 180
- digital clock setting 13
- drive chain 124

E

- engine,
 - does not start 161
 - flooded 22
 - idle speed 74
 - lacks power 161
 - mode select button 139
 - number 168
 - oil 63
 - pinging 54
 - starting 21
 - stop button 22
 - stopping 22
- environment, protecting 160

F

- filter,
 - air 69
 - fuel pump 57
 - oil 64
- flooded engine, starting 22
- fork,
 - front suspension adjustment 140
 - front suspension inspection 99
 - oil recommendation 102
- front brake lever adjustment 116
- front suspension maintenance 140
- fuel 54
- fuel mileage meter 12
- fuel,
 - line inspection 55
 - line replacement 55
 - oxygenated 175
 - pump filter 57
 - refueling 54
 - tank capacity 54