

Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

Importance of Maintenance	P. 31	Engine Oil	P. 56
Maintenance Schedule	P. 32	Coolant	P. 60
Maintenance Fundamentals	P. 35	Brakes	P. 62
Tool Kit	P. 46	Side Stand	P. 65
Removing & Installing Body Components	P. 47	Drive Chain	P. 66
Battery	P. 47	Clutch	P. 70
Battery Maintenance Cover	P. 49	Throttle	P. 73
Clip	P. 50	Crankcase Breather	P. 74
Harness Band Clip	P. 50	Other Adjustments	P. 75
Head Pipe Cover	P. 51	Headlight Aim.....	P. 75
Right Side Cover Assembly	P. 52		
Spark Plug	P. 53		