

# Multi Information Display

---

## Display Illumination Adjustment

To adjust the brightness of the display:

Push the DIM button once. “DIMMER” will display.

- To brighten the display ——— push the TRIP button (+).
- To darken the display ——— push the INFO button (-).  
(The brighter and darker ranges each have six steps.)
- To set the selected step ——— push the SETUP button.

